




























RELAYS

B1-1

<p>RL-11 12V. 40A. RL-21 24V. 30A.</p> <p>0332014150 0332014203</p> <p>L W H 26X26X23</p>  <p>UNIVERSAL</p>	<p>RL-11-1 12V. 40A. RL-21-1 24V. 30A.</p> <p>L W H 26X26X23</p>  <p>UNIVERSAL</p>	<p>RL-11-2T 12V. 30/40A. RL-21-2T 24V. 20/30A.</p> <p>0332014125 0332014203</p> <p>L W H 26X26X23</p>  <p>UNIVERSAL</p>	<p>RL-12 12V. 40A. RL-24 24V. 20A.</p> <p>0332014150 0332014203</p> <p>L W H 28X28X25</p>  <p>UNIVERSAL</p>
<p>RL-12-1 12V. 40A. RL-24-1 24V. 30A.</p> <p>0332014150 0332014203</p> <p>L W H 28X28X25</p>  <p>UNIVERSAL</p>	<p>RL-12-2T 12V. 30/40A. RL-24-2T 24V. 20/30A.</p> <p>0332014151 0332014201</p> <p>L W H 28X28X25</p>  <p>UNIVERSAL DOUBLE CONTACT</p>	<p>RL-13-2T 12V. 30/40A. RL-25-2T 24V. 20/30A.</p> <p>0332014125 0332014203</p> <p>L W H 28X28X25</p>  <p>UNIVERSAL</p>	<p>RL-14-2T 12V. 30/40A. RL-23-2T 24V. 20/30A.</p> <p>L W H 26X26X23</p>  <p>UNIVERSAL</p>
<p>RL-15 12V. 40A RL-22 24V. 30A.</p> <p>L W H 28X28X25</p>  <p>UNIVERSAL</p>	<p>RL-15-1(RL-190A) 12V. 40A. RL-22-1(RL-190B) 24V. 20A.</p> <p>L W H 28X28X25</p>  <p>UNIVERSAL</p>	<p>RL-17-2T 12V. 40X80A. RL-27-2T 24V. 30X50A.</p> <p>0332014157 L W H 29X29X27</p>  <p>UNIVERSAL</p>	<p>RL-18 12V. 70A. 90987-02016 RL-28 24V. 50A. 156700-1570 90987-12002 156700-3130</p> <p>L W H 28X26X25</p>  <p>UNIVERSAL TOYOTA VIGO</p>
<p>RL-19 12V. 40A. RL-29 24V. 30A.</p> <p>L W H 28X28X25</p>  <p>UNIVERSAL</p>	<p>RL-41 12V.25A. 25230-89975 RL-42 24V.15A. 25230-89977 MR5A042-8 1-82550-146-0</p> <p>L W H 28X31X32</p>  <p>NISSAN</p>	<p>RL-44 12V. 30A. 4P</p>  <p>UNIVERSAL</p>	<p>RL-45 12V. 30A. 4P + DIODE</p>  <p>UNIVERSAL</p>
<p>RL-47 12V. 20-25A 4P</p>  <p>UNIVERSAL</p>	<p>RL-150A 12V. 20/30A. 5B-1T RL-150B 24V. 10/20A. 5C-1T</p> <p>25230-C9905 25230-C9900 8-94235-627-0 8-94218-497-0 MR5A-052-8 8-94118-912-0</p>  <p>NISSAN ISUZU</p>	<p>RL-151A 12V. 25AX2 RL-151B 24V. 15AX2 SAME/เหมือนกัน RL-218A</p> <p>RL-218B L W H 28X31X32</p>  <p>G.M. 94118913 ISUZU 8-94423-168-0 NISSAN 25230-C9920 NISSAN ISUZU</p>	<p>RL-153-1A 12V. 22A. 90987-01003 RL-153-1B 24V. 11A. 056700-4800 056700-5250</p>  <p>TOYOTA</p>
<p>RL-153-2A 12V. 22A. 90987-02004 RL-153-2B 24V. 11A. 056700-4810 056700-5260</p>  <p>TOYOTA</p>	<p>RL-154A 12V. 20A. 90987-03001 RL-154B 24V. 15A. Z90987-03002</p>  <p>TOYOTA</p>	<p>RL-155-1A 12V. 40A. 28300-46010 3735060-00</p> <p>L W H 32X28X33</p>  <p>TOYOTA</p>	<p>RL-155-2A 12V. 40A. 90987-02006 3735060-00</p> <p>L W H 32X28X33</p>  <p>TOYOTA</p>

























RELAYS

B1-2












<p>RL-155-3A 12V. 30/40A. RL-155-3B 24V. 15/30A. 90987-04002 39762-SG0-003 056700-9340 L W H 32X28X33</p>  <p>TOYOTA HONDA</p>	<p>RL-156A 12V. 30A. RL-156B 24V. 25A. 056700-7410 765018 39762-SG0-003 056700-9340 L W H 32X28X33</p>  <p>TOYOTA HONDA</p>	<p>RL-157A 12V. 30A. 28300-16100 056700-9000 L W H 32X28X33</p>  <p>TOYOTA</p>	<p>RL-158A 12V. 25A. 90987-30020 L W H 32X28X33</p>  <p>TOYOTA</p>
<p>RL-161A 12V. 20/30A. 156700-0671 28610-67010 L W H 32X28X33</p>  <p>TOYOTA</p>	<p>RL-162A 12V. 30A. 90080-87016 90080-02009 90080-87018 L W H 32X28X31</p>  <p>TOYOTA</p>	<p>RL-163A 12V. 30A. 90987-03003 90987-87017 L W H 32X28X31</p>  <p>TOYOTA</p>	<p>RL-164A 12V. 20/30A. 056700-8520 85910-33010 L W H 32X27X30</p>  <p>TOYOTA</p>
<p>RL-165A 12V. 30A. RL-165B 24V. 20A. 056700-9721 L W H 32X28X35</p>  <p>TOYOTA</p>	<p>RL-167A 12V. 30/40A. RL-167B 24V. 15/30A. 85910-22040 L W H 32X27X30</p>  <p>TOYOTA</p>	<p>RL-168A 12V. 30/40A. RL-168B 24V. 15/30A. 818630-17010 L W H 32X27X30</p>  <p>TOYOTA</p>	<p>RL-169A 12V. 70A. RL-169B 24V. 50A. 8-94248-161-0 AA70A 18-651 8-94423-314-0 8-94153-849-0 L W H 39X35X39</p>  <p>ISUZU HYUNDAI</p>
<p>RL-170A 12V. 70A. RL-170B 24V. 50A. 8-94128-856-0 8-94153-848-0 89920-1790 A 8-94423-315-0 L W H 39X35X39</p>  <p>TOYOTA</p>	<p>RL-171A 12V. 30A. RL-171B 24V. 15A. 90987-01001 90999-99088 94841862 L W H 28X25X33</p>  <p>TOYOTA</p>	<p>RL-172A 12V. 30A. RL-172B 24V. 20A. Mitsubishi MC-848962 MC-854954 MC-852954 L W H 30X25X31</p>  <p>MITSUBISHI NISSAN</p>	<p>RL-173A 12V. 8-97173-951-0 RL-173B 24V. MR82C-741 8-97173-947-0</p>  <p>ISUZU</p>
<p>RL-174A 12V.15A. 25630-79960 RL-174B 24V.10A.</p>  <p>NISSAN</p>	<p>RL-175B 24V. 20A. 85920-1200A 056700-5370</p>  <p>HINO</p>	<p>RL-191A 12V. 40A. RL-191B 24V. 40A. L W H 28x28x25 86 30 85 87 86 87 85 30</p>  <p>UNIVERSAL</p>	<p>RL-195A 12V. 20A. RL-195B 24V. 10A. 26320-17L01 L W H 23X23X33</p>  <p>NISSAN</p>
<p>RL-196A 25630-17L01 RL-196B 25630-C9961 25630-D0100 28300-16100 L W H 25X26X38</p>  <p>NISSAN</p>	<p>RL-199A 12V. 70A. RL-199B 24V. 70A. L W H 26x26x25 86 30 85 87 86 87 85 30</p>  <p>UNIVERSAL</p>	<p>RL-211A 12V. 30A. MB-141967 RL-211B 24V. 15A. MB-141980 L W H 27X23X30</p>  <p>UNIVERSAL</p>	<p>RL-215 12V. 30A. 25230-C9971</p>  <p>NISSAN BACKHOE LOADER</p>

RELAYS

B1-3




















<p>RL-216A 12V. 25A. RL-216B 24V. 15A.</p> <p>L W H 27X23X30</p>  <p>39892-SPO-014 MB-229456 MB-627895</p> <p>UNIVERSAL HONDA MITSUBISHI</p>	<p>RL-217A 12V. 40A. RL-217B 24V. 25630-79962</p>  <p>L W H 32X27X30</p> <p>NISSAN</p>	<p>RL-218A 12V. 20A. RL-218B 24V. SAME/เหมือนกัน RL-151A 25230-C9963 RL-151B</p>  <p>L W H</p>	<p>RL-219A 12V.20A. (BLACK/RED/WHITE/GRAY) RL-219B 24V.</p> <p>L W H 22X15X16</p>  <p>TOYOTA</p>
<p>RL-220A 12V. 20A. RL-220B 24V. 10A.</p> <p>90987-87010 90987-02022</p> <p>L W H 19X15X22</p>  <p>TOYOTA</p>	<p>RL-221 12V. 25A. RL-223 24V. 15A.</p> <p>L W H 28X25X33</p>  <p>8-94112-911-0 8-94118-912-0 MR5L 223 A2K 1-82550-176-0</p> <p>ISUZU</p>	<p>RL-246A 12V. 20/30A. RL-446B 24V. 15/20A.</p> <p>L W H 32X28X33</p>  <p>056700-6210 39797SM4-003 MC-843788 85920-1470 056700-7201</p> <p>TOYOTA MITSUBISHI HONDA</p>	<p>RL-290A 12V. 20A. RL-290B 24V. 10A.</p> <p>L W H 23X15X26</p>  <p>156700-0940 86530-35040 90080-87008 90982-02012 156700-0870</p> <p>TOYOTA</p>
<p>RL-291A 12V. 10/20A. RL-291B 24V. 10/20A.</p> <p>L W H 23X15X26</p>  <p>156700-0860 156700-0930 90080-87009 90987-04004</p> <p>UNIVERSAL</p>	<p>RL-292A 12V. 30A. RL-292B 24V. 20A.</p> <p>L W H 23X18X28</p>  <p>UNIVERSAL</p>	<p>RL-293A 12V. 10/20A. RL-293B 24V. 10/20A.</p> <p>L W H 22X15X22</p> 	<p>RL-294A 12V. 25A. 4P RL-294B 24V. 25A. 4P</p> <p>L W H 20X15X23</p> 
<p>RL-303A 12V 30A. JE16-18-811 RL-303B 24V 20A. JE01-18-811</p> <p>L W H 32X26X30</p>  <p>MITSUBISHI - HONDA</p>	<p>RL-304A</p> <p>L W H 32X26X30</p>  <p>MITSUBISHI</p>	<p>RL-305A 12V30A 4P MC848962 RL-305B 24V20A 4P 704386896</p> <p>L W H 28X23X33</p>  <p>MITSUBISHI</p>	<p>RL-307B 24V. 20A 5P</p> 
<p>RL-307-4P 12V. 30A. 4P</p> 	<p>RL-308-5P 12V. 30/40A. 5P</p> 	<p>RL-0312-6A 12V. 30/40A. 5P RL-0312-6B 24V. 20/30A. 5P</p> <p>L W H 27X27X27</p>  <p>86 30 85 87 87a 86 87a 85 30</p>	<p>RL-971 4P(ขากว้าง)</p>  <p>NISSAN (RELAY MOTOR FAN BIG-M)</p>
<p>RL-972 5P(ขากว้าง)</p>  <p>NISSAN (RELAY MOTOR FAN)</p>	<p>RL-980 12V. 30A. 4P 25230-C9980</p> <p>L W H 27X23X32</p>  <p>NISSAN</p>	<p>RL-999 12V. 15A.</p>  <p>NISSAN</p>	<p>RL-2016A-12V 60A RL-2016B-24V 40A</p>  <p>4P</p>

RELAYS

<p>RL-HFV7/012 12V.70A 4P</p> 	<p>RL-HFV7A 12V. 50A.4P</p> <p>/GREEN /GRAY /BLUE /PURPLE</p> <p>L W H 22X15X20</p>  	<p>RL-HY 12V. 20A. 4P</p> 	<p>AJ51(156700-2560) 12V. 20A 4P</p> 
<p>156200-1780 12V10/20A 5P</p> 	<p>28610-27010 12V. 70A 4P 156700-1860</p> 	<p>90987-02025 12V. 70A 4P</p> 	<p>90987-04010 12V. 70A 5P 156700-2230 156700-3320</p> 
<p>MK387269 24V. 20A 5P 156700-2581</p> 	<p>RL-SN400 12V. 400A</p>  <p>CORE OF CONTROLS</p>		

RELAYS

B1-5

<p>HR-212 12V.30A. HORN RELAY HR-213 24V.20A. HORN RELAY</p> <p>L W H 44X24X29</p>  	<p>HR-214 12V.30A. HORN RELAY HR-215 24V.20A. HORN RELAY</p> <p>L W H 43X29X30</p>  	<p>HR-216 12V.30A. HORN RELAY HR-217 24V.20A. HORN RELAY</p> 	<p>NLR-22 12V. 30A. NLR-44 24V. 20A.</p>  <p>BUS TRUCK ISUZU</p>
<p>NLR-120 12 V. NLR-240 24 V.</p> <p>L W H 43X29X30</p>  	<p>SLR-12 12V. 30A. SLR-24 24V. 15A.</p> <p>L1 S3 L2</p>  <p>S1 B S2</p> 	<p>TMR-101 12V. TMR-102 24V.</p>  <p>UNIVERSAL AUTOMATIC TIMER RELAY</p>	<p>TMR-991 12V. TMR-993 24V.</p>  <p>UNIVERSAL AUTOMATIC TIMER RELAY</p>
<p>BR-121-12V BR-241-24V</p> 	<p>BR-153 12V. ⊖ CUT BR-253 24V. ⊖ CUT</p>  <p>ISUZU BUS,TRUCK TX541,542,552 62-68 BR351,751 BA741, BC161 KOMATSU INTERNATIONAL,MITSUI Zosen,NIGATA TEKKOINDUSTRIAL</p>	<p>BR-155 12V. ⊕ CUT</p>  <p>8279-0008 8279-0018 8279-0021 8279-0033 8279-0043 BS-E</p> <p>ISUZU TRUCK KOMATSU INTERNATIONAL INDUSTRIAL</p>	<p>BR-257 24V. ⊕ CUT</p>  <p>ISUZU TRUCK KC320, KF721, KM300, 69-72 TC311,ZM711</p>
<p>BR-261 24V. ⊕ CUT</p>  <p>8279-0052 8279-0055 8279-0065 BS-H BS-Q</p> <p>ISUZU BUS,TRUCK BH20P,TX,TD 69-72</p>	<p>BR-262 24V. ⊕ CUT</p>  <p>8255-0008 60713-52330 BS-262</p> <p>ISUZU BUS, TRUCK TX, TD 73, KOMATSU</p>	<p>BR-265 24V. ⊕ CUT</p>  <p>NISSAN</p>	