









































# UNIVERSAL SWITCHES

<p><b>SW-1</b> ISUZU TRUCK DIESEL ETC. 4 POSITIONS 6 TERMINALS</p> 	<p><b>SW-2</b> HINO TRUCK DIESEL ETC. 4 POSITIONS 6 TERMINALS</p> 	<p><b>SW-2A</b> KOMATSU ISC-20 4 POSITIONS 6 TERMINALS</p> 	<p><b>SW-2B</b> KOMATSU DIESEL 4 POSITIONS 6 TERMINALS</p> 	<p><b>SW-3A</b> TOYOTA PETROL ETC. 3 POSITIONS 3 TERMINALS</p> 
<p><b>SW-3B</b> 3 POSITIONS 3 TERMINALS</p> 	<p><b>SW-4A</b> TOYOTA PETROL ETC. 4 POSITIONS 4 TERMINALS</p> 	<p><b>SW-4B</b> TOYOTA DIESEL ETC. 4 POSITIONS 4 TERMINALS</p> 	<p><b>SW-5A</b> STARTER / HORNS 2 TERMINALS DC 12-24V 10A</p> 	<p><b>SW-5B</b> STARTER / HORNS 2 TERMINALS DC 12-24V 10A</p> 
<p><b>SW-5C</b> STARTER / HORNS BLACK, RED, WHITE 2 TERMINALS DC 12-24V 10A</p> 	<p><b>SW-5D</b> STARTER / HORNS 2 TERMINALS DC 12-24V 10A</p> 	<p>STARTER BUTTON SWITCH <b>SW-05E-R-12V</b> ● OFF-ON <b>SW-05E-G-12V</b> ● <b>SW-05E-B-12V</b> ● <b>SW-05E-Y-12V</b> ● <b>SW-05E-R-24V</b> <b>SW-05E-G-24V</b> <b>SW-05E-B-24V</b> <b>SW-05E-Y-24V</b> 3 TERMINALS 50A 12V DC</p> 	<p><b>SW-5H/R</b> ● <b>SW-5H/O</b> ● <b>SW-5H/G</b> ●</p>  <p>2 TERMINALS</p>	<p><b>SW-5I/R</b> ● <b>SW-5I/O</b> ● <b>SW-5I/G</b> ●</p>  <p>2 TERMINALS</p>
<p><b>SW-5J/R</b> ● <b>SW-5J/O</b> ● <b>SW-5J/G</b> ●</p>  <p>2 TERMINALS</p>	<p><b>SW-6NA</b> OFF/ON AMBER,BLUE,GREEN,RED 3 TERMINALS DC 12V 20A</p>  <p>TOGGLE WITH LAMP</p>	<p><b>SW-6NB</b> OFF/ON 2 TERMINALS DC 12V 20A</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-6NC</b> ON/ON <b>SW-6ND</b> ON/OFF/ON 3 TERMINALS DC 12V 20A</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-7</b> ON/OFF/ON 3 TERMINALS DC 12V 15A</p>  <p>TOGGLE SWITCH</p>
<p><b>SW-7A</b> ON-OFF-ON 3 TERMINALS 8A 125V/250V AC</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-7B</b> ON-OFF-ON 3 TERMINALS 10A 125V/6A 250V AC</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-7C</b> ON-OFF-ON 3 TERMINALS</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-8</b> ON/ON TERMINALS DC. 12V. 15 A 3</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-9</b> OFF/ON AMBER,BLUE,GREEN,RED 3 TERMINALS DC. 12V. 20 A.</p>  <p>TOGGLE WITH LAMP</p>
<p><b>SW-10A</b> OFF/ON 2 TERMINALS DC.20 A.</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-10B</b> ON/ON <b>SW-10C</b> ON/OFF/ON 3 TERMINALS DC.20 A.</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-11</b> OFF/(MOMENTARY) ON 2 TERMINALS DC.10A.</p>  <p>HORN SWITCH</p>	<p><b>SW-11B</b> OFF / (MOMENTARY) ON 2 TERMINALS DC.10A.</p>  <p>HORN SWITCH</p>	<p><b>SW-12</b> OFF/(MOMENTARY) ON 2 TERMINALS DC 10A</p>  <p>HORN SWITCH</p>
<p><b>SW-13A</b> OFF/ON AMBER,BLUE,GREEN,RED 3 TERMINALS DC 12-24V 20A</p>  <p>ROCKER SWITCH</p>	<p><b>SW-13B</b> OFF/ON 2 TERMINALS DC 12V 20A</p>  <p>ROCKER SWITCH</p>	<p><b>SW-13C</b> ON/ON 3 TERMINALS DC 12V 20A</p>  <p>ROCKER SWITCH</p>	<p><b>SW-13S-NA-12V</b> ON-OFF 2 TERMINALS 12A 125V/6A 250V AC</p>  <p>ROCKER SWITCH</p>	<p><b>SW-13S-NB-12V</b> ON-OFF-ON <b>SW-13S-NC-12V</b> ON-ON 3 TERMINALS 12A 125V/6A 250V AC</p>  <p>ROCKER SWITCH</p>
<p><b>SW-14NA</b> OFF/ON 3 TERMINALS DC 12-24V 20A</p>  <p>ROCKER SWITCH</p>	<p><b>SW-14NB</b> ON/OFF/ON <b>SW-14NC</b> ON/ON 4 TERMINALS DC 12-24V 20A</p>  <p>ROCKER SWITCH</p>	<p><b>SW-15-1</b> OFF/ON 2 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>	<p><b>SW-15A</b> OFF/ON 2 TERMINALS</p>  <p>← 49 mm. →</p> <p>PUSH-PULL SWITCH</p>	<p><b>SW-15B</b> OFF/ON 2 TERMINALS</p>  <p>← 58 mm. →</p> <p>PUSH-PULL SWITCH</p>

# UNIVERSAL SWITCHES

<p><b>SW-15C</b> OFF/ON 2 TERMINALS</p>  <p>← 64 mm. →</p> <p>PUSH-PULL SWITCH</p>	<p><b>SW-16A</b> OFF/ON 2 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>	<p><b>SW-16B</b> OFF/ON 2 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>	<p><b>SW-16C</b> OFF/ON 2 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>	<p><b>SW-17A</b> OFF/ON/ON 4 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>
<p><b>SW-17B</b> OFF/ON/ON 4 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>	<p><b>SW-17C</b> OFF/ON/ON 4 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>	<p><b>SW-17D</b> OFF/ON/ON/ON 5 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>	<p><b>SW-17E</b> 5 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>	<p><b>SW-17G</b> OFF/ON/ON NISSAN 620 4 TERMINALS</p>  <p>PUSH-PULL SWITCH</p>
<p><b>SW-17H</b> SWITCH 5 TERMINALS</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-18</b> OFF/ON 2 TERMINALS</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-19A</b> STOP SWITCH 2 TERMINALS TOYOTA 165001-0000, 83420-10012,20</p>  <p>STOP SWITCH</p>	<p><b>SW-19B</b> NISSAN 720 25320-H8500 2 TERMINALS</p>  <p>STOP SWITCH</p>	<p><b>SW-19C</b> STOP SWITCH 2 TERMINALS MAZDA,SUZUKI, HYUNDAI , MITSUBISHI L300 MB113078,MT138890</p>  <p>STOP SWITCH</p>
<p><b>SW-19D</b> STOP SWITCH 2 TERMINALS ISUZU 94362524, NISSAN 25320-75A00</p>  <p>DIMMER SWITCH</p>	<p><b>SW-20A</b> 3 TERMINALS TOYOTA ETC.</p>  <p>DIMMER SWITCH</p>	<p><b>SW-20B</b> 3 TERMINALS</p>  <p>DIMMER SWITCH</p>	<p><b>SW-21</b> 3 TERMINALS ISUZU ETC.</p>  <p>DIMMER SWITCH</p>	<p><b>SW-22</b> 5 POSITIONS 5 TERMINALS SUIT ALL VEHICLES</p>  <p>AIR CON. (ROTARY)</p>
<p><b>SW-23</b> AIR CON. (SLIDE) 5 POSITIONS 5 TERMINALS SUIT ALL TOYOTA&amp;UNIVERSAL</p>  <p>UNIVERSAL</p>	<p><b>SW-24</b> 12 V. HAZARD WARNING <b>SW-25</b> 24 V.</p>  <p>UNIVERSAL</p>	<p><b>SW-26</b> 5 TERMINALS DC. 12 V. UNIVERSAL</p>  <p>POWER WINDOW</p>	<p><b>SW-27</b> 5 TERMINALS DC. 12 V. UNIVERSAL</p>  <p>POWER WINDOW</p>	<p><b>SW-27C</b> POWER WINDOWS CONTROL</p>  <p>POWER WINDOWS CONTROL</p>
<p><b>SW-28A</b> 12 V. TOYOTA VIGO</p>  <p>CIGARETTE LIGHTER</p>	<p><b>SW-28</b> 12 V. UNIVERSAL</p>  <p>CIGARETTE LIGHTER</p>	<p><b>SW-29</b> 24 V. UNIVERSAL</p>  <p>CIGARETTE LIGHTER</p>	<p><b>SW-30A</b> 12 V. TOYOTA VIGO</p>  <p>CIGARETTE LIGHTER</p>	<p><b>SW-30</b> 12 V. <b>SW-31</b> 24 V. UNIVERSAL</p>  <p>CIGARETTE LIGHTER PLUG</p>
<p><b>SW-32</b> UNIVERSAL</p>  <p>CIGARETTE LIGHTER SOCKET</p>	<p><b>SW-33</b> OFF/ON 3 TERMINALS DC. 12 V. 20 A. AMBER,BLUE,GREEN,RED</p>  <p>ROCKER WITH LAMP</p>	<p><b>SW-34A</b> OFF / ON 2 TERMINALS DC. 12 V. 20 A.</p>  <p>ROCKER SWITCH</p>	<p><b>SW-34B</b> ON / ON 3 TERMINALS DC. 12 V. 20 A.</p>  <p>ROCKER SWITCH</p>	<p><b>SW-35A</b> OFF/ON AMBER,BLUE,GREEN,RED 3 TERMINALS</p>  <p>ROCKER WITH LAMP</p>
<p><b>SW-35B</b> OFF/ON 3 TERMINALS DC. 12 V. 20 A. AMBER,BLUE,GREEN,RED</p>  <p>ROCKER WITH LAMP</p>	<p><b>SW-35C</b> OFF/ON 3 TERMINALS DC. 12 V. 20 A AMBER,BLUE,GREEN,RED</p>  <p>ROCKER WITH LAMP</p>	<p><b>SW-36A</b> (REMOVABLE KEY) 2 TERMINALS HEAVY-DUTY</p>  <p>BATTERY MASTER SWITCH</p>	<p><b>SW-36B</b> (REMOVABLE KEY) 2 TERMINALS</p>  <p>BATTERY MASTER SWITCH</p>	<p><b>SW-36C</b> 12-24V 200A 2 TERMINALS</p>  <p>MOTOR SWITCH</p>

# UNIVERSAL SWITCHES

## A1-3

<p><b>SW-36D</b> 12-24V 200A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36E</b> 12-24V 200A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36F</b> 12-24V 250A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36G</b> 12-24V 200-500A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36H</b> 12-24V</p>  <p>MOTOR SWITCH</p>
<p><b>SW-36i</b> 12-24V 1500A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36J</b> 12-24V 1000A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36K</b> 12-24V 200A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36L</b> 12-24V 200A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36M</b> 12-24V 250A</p>  <p>MOTOR SWITCH</p>
<p><b>SW-36N</b> 12-24V 200-500A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36P</b> 12-24V 200-500A</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36Q</b> 12-24V</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36R</b> 12-24V</p>  <p>MOTOR SWITCH</p>	<p><b>SW-36S</b> 12-24V</p>  <p>MOTOR SWITCH</p>
<p><b>SW-39A</b> 5 TERMINALS NISSAN720,B11(48750-D0100)</p>  <p>IGNITION SWITCH</p>	<p><b>SW-39B</b> 5 TERMINALS NISSAN B310 (48750-E4700)</p>  <p>IGNITION SWITCH</p>	<p><b>SW-39C</b> 5 TERMINALS (48750-D4000) NISSAN 720 D21 PICK UP</p>  <p>IGNITION SWITCH</p>	<p><b>SW-40-1 SW-40-2</b> (MIDDLE POSITION)</p>  <p>SOCKET SWITCH</p>	<p><b>SW-40-3 SW-40-4</b> (SIDE POSITION)</p>  <p>SOCKET SWITCH</p>
<p><b>SW-40A</b> OFF/ON ROCKER SWITCH HEAD LAMP SYMBOL 6 TERMINALS</p> 	<p><b>SW-40B</b> OFF/ON ROCKER SWITCH STOP ENGINE SYMBOL 6 TERMINALS</p> 	<p><b>SW-40C</b> OFF/ON ROCKER SWITCH HAZARD WARNING SYMBOL 6 TERMINALS</p> 	<p><b>SW-40D</b> OFF/ON ROCKER SWITCH FAN SYMBOL 6 TERMINALS</p> 	<p><b>SW-40E</b> OFF/ON ROCKER SWITCH SIGNAL SYMBOL 6 TERMINALS</p> 
<p><b>SW-40F</b> OFF/ON ROCKER SWITCH HORN SYMBOL 5 TERMINALS</p> 	<p><b>SW-40G</b> OFF/ON ROCKER SWITCH TV SYMBOL 6 TERMINALS</p> 	<p><b>SW-40H</b> OFF/ON ROCKER SWITCH WIPER SYMBOL 6 TERMINALS</p> 	<p><b>SW-40I</b> OFF/ON ROCKER SWITCH FOG LAMP SYMBOL 6 TERMINALS</p> 	<p><b>SW-40J</b> OFF/ON ROCKER SWITCH 4 TERMINALS</p> 
<p><b>SW-40K</b> OFF/ON ROCKER SWITCH 4 TERMINALS</p> 	<p><b>SW-40L</b> OFF/ON ROCKER SWITCH 4 TERMINALS</p> 	<p><b>SW-41</b> OFF/ON A/C SYMBOL PUSH SWITCH 6 TERMINALS</p> 	<p><b>SW-42</b> OFF/ON HAZARD WARNING SYMBOL PUSH SWITCH 8 TERMINALS</p> 	<p><b>SW-43</b> OFF/ON FOG LAMP SYMBOL PUSH SWITCH 5 TERMINALS</p> 
<p><b>SW-44</b> OFF/ON (AMBER,BLUE,GREEN,RED) 3 TERMINALS DC. 12V. 25A.</p>  <p>TOGGLE SWITCH WITH(LED)</p>	<p><b>SW-45</b> OFF/ON (AMBER,BLUE,GREEN,RED) 3 TERMINALS DC. 12 V. 20 A.</p>  <p>TOGGLE SWITCH WITH(LED)</p>	<p><b>SW-45/1</b> = Black <b>SW-45/2</b> = Red <b>SW-45/3</b> = Green <b>SW-45/4</b> = Blue <b>SW-45/5</b> = Clear <b>SW-45/6</b> = Orange</p>  <p>SAFETY COVER</p>	<p><b>SW-46</b> OFF/ON L.E.D. RED 4 TERMINALS DC. 12V. 35A.</p>  <p>ROCKER SWITCH WITH</p>	<p><b>SW-47</b> OFF/(ON) UNIVERSAL DC. 12 V. 20 A.</p>  <p>DOOR SWITCH</p>

# UNIVERSAL SWITCHES

## A1-4

<p><b>SW-48</b> OFF/(ON) UNIVERSAL DC. 12 V. 20 A.</p>  <p>DOOR SWITCH</p>	<p><b>SW-49A</b> (AMBER,BLUE,GREEN,RED) 3 TERMINALS DC. 12 V. 15 A. ROCKER SWITCH WITH LAMP</p> 	<p><b>SW-49B</b> L.E.D. (AMBER,BLUE,GREEN,RED) 3 TERMINALS DC. 12V. 20A.</p>  <p>ROCKER SWITCH WITH LAMP</p>	<p><b>SW-50A/R</b> 24V <b>SW-50A/O</b> <b>SW-50A/G</b></p>  <p>OFF-ON 250V 4A (4 PIN)</p>	<p><b>SW-51A/R</b> 24V <b>SW-51A/O</b> <b>SW-51A/G</b></p>  <p>ON-OFF 250V 3A(6 PIN)</p>
<p><b>SW-52NA</b> ON-OFF RED/ORANGE/GREEN 3 TERMINALS 12V DC</p>  <p>ROCKER SWITCH(LEN&amp;LED)</p>	<p><b>SW-52NB</b> ON-OFF-ON 12V 20A 125V/10A 250V AC 3 TERMINALS</p>  <p>ROCKER SWITCH</p>	<p><b>SW-52NC</b> ON-ON 12V 20A 125V/10A 250V AC 3 TERMINALS</p>  <p>ROCKER SWITCH</p>	<p><b>SW-53NB-12V</b> ON-OFF-ON 6 TERMINALS 21A 14V DC</p>  <p>ROCKER SWITCH</p>	<p><b>SW-54</b> 12-36 V. 2 TERMINALS</p>  <p>SWITCH BREAK</p>
<p><b>SW-101A</b> OFF/ON <b>SW-101B</b> 2 TERMINALS 10A. 250VAC,15A.125VAC</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-103A</b> ON/OFF/ON <b>SW-103B</b> 3 TERMINALS 10A. 250VAC,15A.125VAC</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-201A</b> OFF/ON <b>SW-201B</b> 4 TERMINALS 10A. 250VAC,15A.125VAC</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-203A</b> ON/OFF/ON <b>SW-203B</b> 6 TERMINALS 10A. 250VAC,15A.125VAC</p>  <p>TOGGLE SWITCH</p>	<p><b>SW-738</b> 6 TERMINALS T/T MIGHTY</p> 
<p><b>SW-1000</b> สวิตซ์เท้าเหยียบเครื่องจักร</p> 	<p><b>SW-5801</b> CATERPILLAR 2 TERMINALS</p>  <p>BATTERY SWITCH</p>	<p><b>SW-5810</b> CATERPILLAR 3 TERMINALS</p>  <p>STARTER SWITCH</p>	<p><b>SW-USB-01</b></p>  <p>BLACK RED WHITE YELLOW PINK ORANGE BLUE LIGHT PINK VIOLET DC 12V-24V OUT PUT:5.0-1000mA USB CAR CHARGER</p>	<p><b>SW-USB-VIGO</b></p>  <p>Port 1 : 1.2A (Smart Phone) Port 2 : 2.1A (Tablet PC)</p> <p><b>TOYOTA VIGO</b> DC 12V-24V</p> <p>พอร์ท USB แบบ 2 ช่อง สำหรับชาร์จไฟในรถ</p>
<p><b>SW-USB-TOYOTA</b></p>  <p>Port 1 : 1.2A (Smart Phone) Port 2 : 2.1A (Tablet PC)</p> <p><b>TOYOTA</b> *มียางปิด DC 12V-24V พอร์ท USB แบบ 2 ช่อง สำหรับชาร์จไฟในรถ</p>				