

HYUNDAI EXEL

21860-24010

21640-21010

21840-24010

21834-22030



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21860-24010		INSULATOR ENGINE	HYUNDAI		21860-24010
21640-21010		ENGINE BUSHING	HYUNDAI EXCEL		21640-21010
21840-24010		INSULATOR ENGINE	HYUNDAI		21840-24010
21834-22030		ENGINE BUSHING	HYUNDAI ACCENT		21834-22030

21872-21000/21835-21000

1841-02000/21840-02000/2184

21835-21000

54555-28001



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21872-21000/21835-21000		ENGINE BUSHING	HYUNDAI EXCEL		21872-21000/21835-21000
21841-02000/21840-02000/21841		ENGINE BUSHING	HYUNDAI		21841-02000/21840-02000/21841
21835-21000		ENGINE BUSHING	HYUNDAI EXCEL		21835-21000
54555-28001		LOWER ARM BUSHING	HYUNDAI		54555-28001

54555-28002

54610-24001



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54555-28002		LOWER ARM BUSHING	HYUNDAI		54555-28002
54610-24001		SHOCK ABSORBER MOUNT	EXCEL		54610-24001



21830-22030/22020/22720		ENGINE BUSHING	HYUNDAI ACCENT		21830-22030/22020/22720
21830-22100/22720/22020		ENGINE BUSHING	HYUNDAI ACCENT		21830-22100/22720/22020
21830-22721/22720/22020		ENGINE BUSHING	HYUNDAI ACCENT		21830-22721/22720/22020
21830/2D050/21832-2D000		ENGINE BUSHING	HYUNDAI		21830/2D050/21832-2D000



21810-22000/21834-22030		ENGINE BUSHING	HYUNDAI ACCENT		21810-22000/21834-22030
21810-22040/21834-22030		ENGINE BUSHING	HYUNDAI ACCENT		21810-22040/21834-22030
21813-4A051		ENGINE BUSHING	HYUNDAI H1		21813-4A051
21830-22000		ENGINE BUSHING	HYUNDAI ACCENT		21830-22000

HYUNDAI ACCENT

21830-22720



21830-22020



21832-2D000



21850-24010/MB-309183



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21830-22720		ENGINE BUSHING	HYUNDAI ACCENT		21830-22720
21830-22020		ENGINE BUSHING	HYUNDAI ACCENT		21830-22020
21832-2D000		ENGINE BUSHING	HYUNDAI		21832-2D000
21850-24010/MB-309183		ENGINE BUSHING	HYUNDAI ACCENT		21850-24010/MB-309183

21391-28001/MB-309266



21810-23610/MB-436022



21810-23630/MB-436022



21810-24110/MB-436022



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21391-28001/MB-309266		ENGINE BUSHING	HYUNDAI ACCENT		21391-28001/MB-309266
21810-23610/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21810-23610/MB-436022
21810-23630/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21810-23630/MB-436022
21810-24110/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21810-24110/MB-436022

21810-28000/MB-436022



21810-34200/MB-436022



21830-22420/MB-436022



21830-33470/MB-436022



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21810-28000/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21810-28000/MB-436022
21810-34200/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21810-34200/MB-436022
21830-22420/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21830-22420/MB-436022
21830-33470/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21830-33470/MB-436022

21830-33510/MB-436022



21834-24800/MB-436022



21640-33410/MB-438699



21840-22000/MB-438699



21830-33510/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21830-33510/MB-436022
21834-24800/MB-436022		ENGINE BUSHING	HYUNDAI ACCENT		21834-24800/MB-436022
21640-33410/MB-438699		ENGINE BUSHING	HYUNDAI ACCENT		21640-33410/MB-438699
21840-22000/MB-438699		ENGINE BUSHING	HYUNDAI ACCENT		21840-22000/MB-438699



21840-22300/MB-438699		ENGINE BUSHING	HYUNDAI ACCENT		21840-22300/MB-438699
21840-22600/MB-438699		ENGINE BUSHING	HYUNDAI ACCENT		21840-22600/MB-438699
21910-28000/MB-438699		ENGINE BUSHING	HYUNDAI ACCENT		21910-28000/MB-438699
21911-28000/MB-438699		ENGINE BUSHING	HYUNDAI ACCENT		21911-28000/MB-438699

HYUNDAI ACCENT

21840-22700/MB-581297

21850-22300/MB-591322

21930-34300/MB-591322

21850-22702/MB-309183



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21840-22700/MB-581297		ENGINE BUSHING	HYUNDAI ACCENT		21840-22700/MB-581297
21850-22300/MB-591322		ENGINE BUSHING	HYUNDAI ACCENT		21850-22300/MB-591322
21930-34300/MB-591322		ENGINE BUSHING	HYUNDAI ACCENT		21930-34300/MB-591322
21850-22702/MB-309183		ENGINE BUSHING	HYUNDAI ACCENT		21850-22702/MB-309183

54551-02000

54556-22102/22000

54555-22102

54551-25000



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54551-02000		LOWER ARM BUSHING	HYUNDAI		54551-02000
54556-22102/22000		LOWER ARM BUSHING (RH)	HYUNDAI ACCENT		54556-22102/22000
54555-22102		LOWER ARM BUSHING (LH)	HYUNDAI ACCENT		54555-22102
54551-25000		LOWER ARM BUSHING	HYUNDAI		54551-25000

54551-02000

54813-22200



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54551-02000		LOWER ARM BUSHING	HYUNDAI		54551-02000
54813-22200		Stabilizer Shaft Rubber (FR)	HYUNDAI		54813-22200



21803-28700/MB-436900		ENGINE BUSHING	HYUNDAI ELANTRA		21803-28700/MB-436900
21812-28250/MB-436900		ENGINE BUSHING	HYUNDAI ELANTRA		21812-28250/MB-436900
21830-23200/MB-436900		ENGINE BUSHING	HYUNDAI ELANTRA		21830-23200/MB-436900
21830-28260/MB-436900		ENGINE BUSHING	HYUNDAI ELANTRA		21830-28260/MB-436900



21830-28700/MB-436900		ENGINE BUSHING	HYUNDAI ELANTRA		21830-28700/MB-436900
21830-28860/MB-436900		ENGINE BUSHING	HYUNDAI ELANTRA		21830-28860/MB-436900
21830-34200/MB-436900		ENGINE BUSHING	HYUNDAI ELANTRA		21830-34200/MB-436900
21830-34321/MB-436900		ENGINE BUSHING	HYUNDAI ELANTRA		21830-34321/MB-436900

HYUNDAI ELANTRA

21930-28860/MB-844289

21930-29310/MB-844289

21872-36000

21911-39090



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21930-28860/MB-844289		ENGINE BUSHING	HYUNDAI ELANTRA		21930-28860/MB-844289
21930-29310/MB-844289		ENGINE BUSHING	HYUNDAI ELANTRA		21930-29310/MB-844289
21872-36000		ENGINE BUSHING	HYUNDAI		21872-36000
21911-39090		ENGINE BUSHING	SONATA		21911-39090

21910-28500/21910-28500

21910-29001/21910-28500

21960-28860/21910-28500

21850-24710/MB-309269



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21910-28500/21910-28500		ENGINE BUSHING	HYUNDAI ELANTRA		21910-28500/21910-28500
21910-29001/21910-28500		ENGINE BUSHING	HYUNDAI ELANTRA		21910-29001/21910-28500
21960-28860/21910-28500		ENGINE BUSHING	ELANTRA		21960-28860/21910-28500
21850-24710/MB-309269		ENGINE BUSHING	HYUNDAI ELANTRA		21850-24710/MB-309269

21930-29000/MB-309269

21930-34200/MB-309269

21931-28500

21810-28500



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21930-29000/MB-309269		ENGINE BUSHING	HYUNDAI ELANTRA		21930-29000/MB-309269
21930-34200/MB-309269		ENGINE BUSHING	HYUNDAI ELANTRA		21930-34200/MB-309269
21931-28500		ENGINE BUSHING	HYUNDAI ELANTRA		21931-28500
21810-28500		ENGINE BUSHING	HYUNDAI ELANTRA		21810-28500

21930-28300

21631-33410/21631-33710

21850-23600/MB-309269

21810-28250/MB-436537



21930-28300		ENGINE BUSHING	HYUNDAI ELANTRA		21930-28300
21631-33410/21631-33710		ENGINE BUSHING	HYUNDAI ELANTRA		21631-33410/21631-33710
21850-23600/MB-309269		ENGINE BUSHING	HYUNDAI ELANTRA		21850-23600/MB-309269
21810-28250/MB-436537		ENGINE BUSHING (LH)	(GALANT GTI)		21810-28250/MB-436537



21810-34321/MB-436537		ENGINE BUSHING (LH)	(GALANT GTI)		21810-34321/MB-436537
21810-35000/MB-436537		ENGINE BUSHING (LH)	(GALANT GTI)		21810-35000/MB-436537
21820-28270/MB-436537		ENGINE BUSHING (LH)	(GALANT GTI)		21820-28270/MB-436537
54583-29000		LOWER ARM BUSHING	HYUNDAI ELANTRA96		54583-29000

HYUNDAI ELANTRA

54584-29000

54584-29000B

54551-28000/28310

54551-29010/29000



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54584-29000		LOWER ARM BUSHING	HYUNDAI ELANTRA96		54584-29000
54584-29000B		LOWER ARM BUSHING	HYUNDAI ELANTRA96		54584-29000B
54551-28000/28310		LOWER ARM BUSHING	HYUNDAI ELANTRA96		54551-28000/28310
54551-29010/29000		LOWER ARM BUSHING	HYUNDAI		54551-29010/29000

54610-28000

55513-29100

54813-28001

54813-29100



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54610-28000		SHOCK ABSORBER MOUNT	HYUNDAI ELANTRA		54610-28000
55513-29100		STABILIZER SHAFT RUBBER	HYUNDAI		55513-29100
54813-28001		STABILIZER RUBBER	HYUNDAI ELANTRA '92, 94		54813-28001
54813-29100		STABILIZER SHAFT RUBBER	HYUNDAI ELANTRA 96		54813-29100

HYUNDAI SONATA

21631-63000

21641-33410

21851-02050

21872-33070



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21631-63000		ENGINE BUSHING	HYUNDAI		21631-63000
21641-33410		ENGINE BUSHING	HYUNDAI		21641-33410
21851-02050		ENGINE BUSHING	HYUNDAI		21851-02050
21872-33070		ENGINE BUSHING	HYUNDAI		21872-33070



21911-34550		ENGINE BUSHING	HYUNDAI		21911-34550
21911-38570		ENGINE BUSHING	HYUNDAI		21911-38570
21640-33066/21641-36000		ENGINE BUSHING	HYUNDAI		21640-33066/21641-36000
21640-33170/21641-36000		ENGINE BUSHING	HYUNDAI		21640-33170/21641-36000



21680-33070/21872-33070		ENGINE BUSHING	HYUNDAI		21680-33070/21872-33070
21872-30070/21872-33070		ENGINE BUSHING	HYUNDAI		21872-30070/21872-33070
21960-33470/21872-33070		ENGINE BUSHING	HYUNDAI		21960-33470/21872-33070
21830-37422/21872-36000		ENGINE BUSHING	HYUNDAI		21830-37422/21872-36000

HYUNDAI SONATA

21910-38650/21911-38470

21960-38100/1911-38570

21910-38600/21911-39090

54555-36010/MB-518095



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21910-38650/21911-38470		ENGINE BUSHING	HYUNDAI		21910-38650/21911-38470
21960-38100/1911-38570		ENGINE BUSHING	HYUNDAI		21960-38100/1911-38570
21910-38600/21911-39090		ENGINE BUSHING	HYUNDAI		21910-38600/21911-39090
54555-36010/MB-518095		LOWER ARM BUSHING (LH)	HYUNDAI SONATA ' 94, 97		54555-36010/MB-518095

54556-36010/MB-518095

54581-35000B

54581-35000S

54551-37000



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54556-36010/MB-518095		LOWER ARM BUSHING (RH)	HYUNDAI SONATA ' 94, 97		54556-36010/MB-518095
54581-35000B		LOWER ARM BUSHING (BIG)	SONATA95,99		54581-35000B
54581-35000S		LOWER ARM BUSHING (SMA)	SONATA95,99		54581-35000S
54551-37000		LOWER ARM BUSHING	HYUNDAI SONATA 95,97		54551-37000

5516-37000

55543-35000

54610-34010

54813-34000



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
55116-37000		LOWER ARM BUSHING	SONATA 95,97		55116-37000
55543-35000		LOWER ARM BUSHING	HYUNDAI SONATA94,97		55543-35000
54610-34010		SHOCK ABSORBER MOUNT	HYUNDAI		54610-34010
54813-34000		STABILIZER RUBBER	HYUNDAI SONATA ' 94, 97		54813-34000

55577-34000



55577-34000		STABILIZER RUBBER	HYUNDAI SONATA ' 94, 97		55577-34000
-------------	--	-------------------	-------------------------	--	-------------



21811-4A000		ENGINE MOUNTING	HYUNDAI H 1		21811-4A000
21811-4B021		ENGINE MOUNTING	HYUNDAI H 1		21811-4B021
21813-43010		ENGINE BUSHING	HYUNDAI H 1		21813-43010
21813-4A001		ENGINE BUSHING	HYUNDAI H 1		21813-4A001

HYUNDAI H1 MINIBUS

54813-4A000

54630-4A000

55256-44000

55257-44000



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54813-4A000		STABILIZER SHAFT RUBBER	HYUNDAI		54813-4A000
54630-4A000		STRUT BAR RUBBER	HYUNDAI H1		54630-4A000
55256-44000		SPRING SHACKLE RUBBER	HYUNDAI H1		55256-44000
55257-44000		SPRING SHACKLE RUBBER	HYUNDAI H1		55257-44000

HYUNDAI H100

21641-36000

21811-43002/21813-43010

54522-43500



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21641-36000		ENGINE BUSHING	HYUNDAI SONATA		21641-36000
21811-43002/21813-43010		ENGINE BUSHING	HYUNDAI H100		21811-43002/21813-43010
54522-43500		LOWER ARM BUSHING	HYUNDAI		54522-43500

HYUNDAI ENGINE BUSHING

21840-02000

21850-02050

21640-21010

21860-24010



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
21840-02000		ENGINE BUSHING	HYUNDAI		21840-02000
21850-02050		ENGINE BUSHING	HYUNDAI		21850-02050
21640-21010		ENGINE BUSHING	HYUNDAI		21640-21010
21860-24010		ENGINE BUSHING	HYUNDAI		21860-24010

21812-28200

54584-38600

21631-33710



21812-28200		ENGINE BUSHING	HYUNDAI		21812-28200
54584-38600		ENGINE BUSHING	HYUNDAI		54584-38600
21631-33710		ENGINE BUSHING	HYUNDAI		21631-33710



54584-38000K		LOWER ARM BUSHING	HYUNDAI		54584-38000K
35654-20060		LOWER ARM BUSHING	HYUNDAI		35654-20060
54443-38000		LOWER ARM BUSHING	HYUNDAI		54443-38000
55541-28310		LOWER ARM BUSHING	HYUNDAI ELANTRA92,94		55541-28310

HYUNDAI ARM BUSHING

55543-37000

MB-54583/84

SUM-001

54551-36000



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
55543-37000		LOWER ARM BUSHING	HYUNDAI SONATA94,		55543-37000
MB-54583/84		LOWER ARM BUSHING	HYUNDAI		MB-54583/84
SUM-001		LOWER ARM BUSHING	HYUNDAI		SUM-001
54551-36000		LOWER ARM BUSHING	HYUNDAI		54551-36000

54555-25000

54443-38000

224-007

54555-28000



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54555-25000		LOWER ARM BUSHING	HYUNDAI		54555-25000
54443-38000		LOWER ARM BUSHING	HYUNDAI		54443-38000
224-007		LOWER ARM BUSHING	HYUNDAI		224-007
54555-28000		LOWER ARM BUSHING	HYUNDAI		54555-28000

54551-24001

54580-35000 BR

54581-35000 BR

54584-28600



ITEMCODE	CODE	DESCRIPTION	CAR MODEL	YEAR	OEM
54551-24001		LOWER ARM BUSHING	HYUNDAI EXCEL,SCOUPE		54551-24001
54580-35000 BR		LOWER ARM BUSHING	HYUNDAI SONATA95,97		54580-35000 BR
54581-35000 BR		LOWER ARM BUSHING	HYUNDAI SONATA95,99		54581-35000 BR
54584-28600		LOWER ARM BUSHING	HYUNDAI		54584-28600

54610-22000

54610-29000

55310-29000

55320-29000

54610-22000		LOWER ARM BUSHING	HYUNDAI		54610-22000
54610-29000		LOWER ARM BUSHING	HYUNDAI		54610-29000
55310-29000		LOWER ARM BUSHING	HYUNDAI		55310-29000
55320-29000		LOWER ARM BUSHING	HYUNDAI		55320-29000



54610-25000			HYUNDAI		54610-25000
MB-176442		STABILIZER RUBBER	HYUNDAI		
54813-34000		STABILIZER RUBBER	HYUNDAI SONATA ' 94, 97		